



EN1723 Dual Input Temperature Sensor Installation Instructions - 05366C

1 Overview

The Inovonics EN1723 provides internal measurement and external thermistor options in a single device. The on-board sensor is excellent for monitoring ambient indoor temperature, and the external sensor is user selectable to match your application.

1.1 Inovonics Wireless Contact Information

If you have any problems with this procedure, contact Inovonics Wireless technical services:

- E-mail: support@inovonics.com
- Phone: (800) 782-2709

1.2 EN1723 Components




Figure 1 EN1723 components

- A Frequency band selection pins B Programming header
C Reset button D Terminal block
E External thermistor selection pins

2 Installation and Startup

2.1 Install/Replace the Battery

1. Pry the top lip of the mounting bracket up, and lift the bracket off of the transmitter.
2. Use your thumb to depress the housing release tab on the bottom of the transmitter; separate the housing.
3. Install the new battery.
4. Press the **Reset** button to initialize the transmitter.

2.2 Mount an External Thermistor

The transmitter uses an on-board thermistor. If you want to use an external thermistor:

1. Wire the external thermistor using 24-gauge wire, no more than 40 feet long.
2. Route the external thermistor wiring through either the rectangular cutouts on the back of the housing and bracket, or through the rounded wiring cutout at the top of the housing.

Note: If you want to use the cutout at the top of the housing, you will need to trim the bracket.

3. Use a small screwdriver to attach the external thermistor wiring leads to the terminal block.
4. Place a jumper on the external thermistor selection pins, allowing the transmitter to use the external thermistor in addition to the on-board thermistor.
5. Press the **Reset** button to complete configuration.

2.3 Select the Frequency Band

EchoStream products are able to use a range of radio frequencies, and must be configured for your geographic area. To configure the transmitter:

1. Place a selection jumper on the appropriate frequency band selection pins.
 - Place the jumper on the top two pins, marked NZ, to set the frequency range to 921-928 MHz for New Zealand.
 - Place the jumper on the bottom two pins, marked AU, to set the frequency range to 915-928 MHz for Australia.
 - Leave the jumper off the pins to set the frequency range to 902-928 MHz for North America.
2. Press the **Reset** button to complete configuration.

Caution: When pressing the **Reset** button, make sure you don't also touch the frequency band selection pins. Touching the frequency band selection pins while pressing the **Reset** button can inadvertently set the transmitter to the wrong frequency band.

3 Program the Transmitter

EN1723 transmitters are programmed at the factory. It is not usually necessary to reprogram EN1723 series transmitters. If you want to reprogram the transmitter, parameters can be changed using the programming header.

4 Mount the Transmitter

1. Attach the mounting bracket to the wall, using either screws or double-sided tape.

Note: There are two mounting holes for standard installation. An optional third mounting hole is located under the battery. Use the third mounting hole to secure the housing to the bracket.

2. Hook the bottom of the transmitter into the bracket's bottom catch, and press the transmitter into the bracket so that the bracket's top lip snaps into place.

5 Television and Radio Interference

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

6 FCC Part 15 Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

7 Warranty/Disclaimer

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Inovonics Wireless Corporation ("Inovonics") warrants its EchoStream products ("Product" or "Products") to conform to its own specifications and to be free of defects in materials and workmanship under normal use for a period of thirty-six (36) months from the date of manufacture. Within the warranty period, Inovonics will repair or replace, at its option, all or any part of the warranted Product. Inovonics will not be responsible for dismantling and/or reinstallation charges. To exercise the warranty, the User ("User", "Installer" or "Consumer") must work directly through their authorized distributor who will be given a Return Material Authorization ("RMA") number by Inovonics. Details of shipment will be arranged directly through the authorized distributor.

This warranty is void in cases of improper installation, misuse, failure to follow installation and operating instructions, alteration, accident or tampering, and repair by anyone other than Inovonics.

This warranty is exclusive and expressly in lieu of all other warranties, obligations or liabilities, whether written, oral, express, or implied. There is no warranty by Inovonics that Inovonics product will be merchantable or fit for any particular purpose, nor is there any other warranty, expressed or implied, except as such is expressly set forth herein. In no event shall Inovonics be liable for an incidental, consequential, indirect, special, or exemplary damages, including but not limited to loss of profit, revenue, or contract, loss of use, cost of down time, or interruption of business, nor any claim made by distributor's customers or any other person or entity.

This warranty will not be modified or extended. Inovonics does not authorize any person to act on its behalf to modify or extend this warranty. This warranty will apply only to Inovonics Products. Inovonics will not be liable for any direct, incidental, or consequential damage or loss whatsoever, caused by the malfunction of Product due to products, accessories, or attachments of other manufacturers, including batteries, used in conjunction with Inovonics Products.