







- A Housing release tab
- **B** Mounting holes
- C Housing tamper switch I Receiver Decode LED
- **D** Reset button

- **G** Power/data terminal block
- **H** EN7286NX dipswitches
- J Receiver Receive LED
- E Relay 1 terminal block K Receiver Transmit LED
- F Relay 2 terminal block L Frequency band selection pins
- M Interface Receive LED
- N Interface Decode LED
- O Interface Serial Receive LED
- **P** Antennas

