ACC680 Alarm Clearance Card
Operation Instructions

1 Overview
The ACC680 alarm clearance card is used to quickly and easily clear alarms from the EN1221S-60N waterproof senior living pendant with neck lanyard and EN1221S-60W waterproof senior living pendant with wristband.

1.1 Inovonics Contact Information

For product and installation videos visit us at www.inovonics.com/videos or use the QR code below.

If you have any problems with this procedure, contact Inovonics technical services:

- E-mail: support@inovonics.com
- Phone: (800) 782-2709; (303) 939-9336

1.2 ACC680 Alarm Clearance Card Components

Figure 1 ACC680 components

2 Operation

2.1 Clear an Alarm
1. Place the dot on the ACC680 alarm clearance card over the activation button.
    - The red transmission LED will cease flashing and the blue alarm clear LED will flash quickly six times to indicate the alarm has cleared.


Figure 2 Place the alarm clearance card over the activation button

3 Specifications
Compatible devices: EN1221S-60N waterproof senior living pendant with neck lanyard; EN1221S-60W waterproof senior living pendant with wristband.

Dimensions: 1.88" x .95" x .13".

Magnet grade: N35.

Magnet materials: Neodymium, iron and boron, with nickel and copper plating.